

Gearbox options

Mounting position

Tandem gearboxes


Overview

The tandem gearbox is mounted in the same position as the main gearbox. The diagrams below are only designed to show the position of the oil control valves of the 2nd gearbox.


Note:

In a horizontal operating position, the convex face of the housing of the 2nd gearbox generally points vertically downwards. For an explanation of the symbols, see [page 10/3](#).

Tandem gearboxes: 2nd gearbox size 19



Tandem gearboxes: 2nd gearbox size 39



Tandem gearboxes: 2nd gearbox sizes 49 to 69

